Vertical Feet Kit Installation Instructions

Use the following instructions to mount the thin client to the vertical feet kit.

1. Remove the four horizontal feet from the thin client by sliding the feet towards the back panel.
2. Rotate the thin client until the power button is towards the top; slide the vertical feet onto the spine at the bottom of the thin client until they snap in place. The first foot snaps twice, once over the first locator position and then again at the second locator position.

Note

For thin client cooling requirements, position the thin client so that the power button to the thin client is on the top when installing in the vertical position.

Note

Leave at least 12.5 mm between the ventilation holes of the thin client and any solid surface. An enclosed area must have a minimum of 150 square cm of venting or other open area to maintain proper ventilation of the thin client.